

ARCFLASHWEAR

Size Chart

AUSTRALIAN FIRE RATED INDUSTRIAL SOCK

Fits Shoe Size	Australia/UK	United States	European
Small	4-8	4-8	37-41
Medium	9-12	9-12	42-45

PR97® AND ULTRASOFT® FR UNIFORM APPAREL

Measuring Tips:

- Use your exact measurements when selecting your size and have someone measure you.
- Measure either directly to your body or in accordance with the garment set you would normally wear. If your measurement is in between two sizes, order the smaller size for a tighter fit or the larger size for a looser fit.
- Neck/Collar - measure around the neck where the top of the shirt collar would sit leaving room for comfort (2 fingers behind the tape).
- Shoulders - measure the width of the shoulders at the widest part.
- Chest - standing naturally, measure around the chest at the fullest part, placing the tape close up under the arms and around the shoulder blades.
- Waist - measure over undergarments at the natural waistline (belt line) keeping one finger between the tape and your body. Measure over your Shirt (not Trousers) at the position you would normally wear your Trousers.
- Hip - measure around the hip at the widest part.
- Inseam - measure from the top of the inside leg at the crotch to the ankle bone.



Recognised throughout the world as a leading textile for secondary protection in the molten metal industry.



Enhanced protection from electric arc and flash fire exposures, as well as multipurpose protection from molten ferrous metal and welding exposures.

ARCFASHWEAR

Size Chart

PR97® AND ULTRASOFT® FR SHIRT (CM)
Allow an Additional Size for the PR97® FR Smelter Coat

Size	S	M	L	XL	2XL	3XL	4XL	5XL
Fit Neck	36-37	38-39	41-42	43-44	45-46	47-48	49-50	51-52
Fit Chest	90	95	100	105	110	115	120	125

PR97® AND ULTRASOFT® FR TROUSER REGULAR (CM)

Size	82R	87R	92R	97R	102R	107R	112R
Waist	82	87	92	97	102	107	112
Inside Leg	76	78	80	82	83	84	85
Outside Leg	101	104.5	108	110	112	114	116

PR97® AND ULTRASOFT® FR TROUSER STOUT (CM)

Size	82ST	87ST	92ST	97ST	102ST	107ST	112ST
Waist	82	87	92	97	102	107	112
Inside Leg	66	68	71	73	76	78	79
Outside Leg	89	92	93	99	103	106	108