

PR97® Care and Maintenance Guide

PR97® garments can be home-washed, commercially laundered or dry-cleaned. They can be effectively repaired or mended using patches and other techniques. However to maximise the service life of PR97® garments and ensure the protective properties of PR97® remain intact, it is important to follow these recommended care guidelines.

DETERGENT

- Use a pH-neutral detergent or one approved by the manufacturer for use with Wool based fabrics.
- Do not use excessive amounts of detergent and follow the manufacturer's guidelines.
- Never use soaps, bleaches or fabric softeners of any kind.

WASH

- Always wash PR97® garments in cold to warm water only; a maximum of 40°C is recommended.
- Separate excessively soiled garments from cleaner garments.
- Do not wash PR97® garments with other types of garments.
- Excessively soiled garments should be pre-soaked in cold to warm water using a pH-neutral detergent prior to washing.
- Minimise the number of garments per load, but maximise water levels.
- Use a gentle wash cycle setting and minimise agitation during rinse and wash cycles.

DRY

- Never dry PR97® garments on hot temperature settings; a maximum of 60°C is recommended.
- Do not tumble dry garments for long periods and do not over dry garments in the drying process, as this could result in excessive shrinkage.
- Do not dry PR97® garments with other types of garments.
- For best results tunnel drying or line drying in the shade is recommended.

MENDING

- Always repair holes or damage to garments prior to washing.
- If patching over holes, always ensure patches seal tightly to the garment surface.
- There should be no lifting of patches, which could cause catch points for metal splash.

This information is provided as a recommended guide only. In all instances end users must firstly satisfy themselves that these guidelines are suitable for their intended application and monitor best care practice throughout a PR97® garment's service life.

BEST TO



Cold/Warm
Water
Max. Temp.



No Bleach
Softener or
Soap



Tumble Dry
Max. 60°C Avoid
Excessive Time



Tunnel Dry/
Line Dry
in Shade



Iron
Low Setting



Professional
Dry Cleaning



Wash
Separately