



Size Chart

DRIFIRE® Horizon FR/AR Vented Work Shirt (RG)

US SIZE *	SM	MD	LG	XL	2X	3X
CHEST Inches Centimetres	34 – 37 86.36 – 93.98	38 – 41 96.52 – 104.14	42 – 45 106.68 – 114.30	46 – 49 116.84 – 124.46	50 – 53 127.0 – 134.62	54 – 57 137.16 – 144.78
WAIST Inches Centimetres	28 - 31 71.12 - 78.74	32 - 35 81.28 - 88.90	36 - 39 91.44 - 99.06	40 - 43 101.60 - 109.22	44 - 47 111.76 - 119.38	48 - 51 121.92 - 129.54

* For Australian Sizing

US flame resistant PPE Shirts are generally one full size larger than Australian sizes. This size difference is driven by two main factors: standard differences between US and Australian sizing conventions and the cut requirements for regional safety standards. American workwear brands design garments with a looser fit to accommodate layering for cold climates and to ensure a full range of movement.

Key Differences Between US and AU Sizing

Men's Sizing (Alpha Sizes): A US Medium usually matches the physical measurements of an Australian Large. If you wear an Australian Large, you will likely need a US Medium.

Measuring Tips

- Use your exact measurements when selecting your size and have someone measure you.
- Measure either directly to your body or in accordance with the garment set you would normally wear. If your measurement is in between two sizes, order the smaller size for a tighter fit or the larger size for a looser fit.
- Chest - you must measure horizontally around the fullest part of your chest, keeping the tape straight across your shoulder blades and directly under your armpits. Because DRIFIRE® Horizon FR Work Shirts use alpha sizing (SM through 3X), the chest circumference is the primary measurement used to determine your correct Shirt size. Accurate sizing ensures that the flame resistant fabric fits comfortably across your upper torso and back, allowing you to reach and bend freely without the buttons pulling or the seams tearing under stress.
- Waist - Measure around your natural waist, where your waist bends side to side. NOTE: This may not be the smallest point. Measurements are body measurements to help determine what size garment a person should order. For best results, measure over fitted undergarments. If your measurement falls between sizes, it is recommended that the larger size be purchased.

Tall sizes are 2" (5.08cms) longer than regular sizes.

Tall alterations have a 1.5" (3.81cms) longer sleeve length than a regular size.

Short alterations have a 1.5" (3.81cms) shorter sleeve length than a regular size.