



Size Chart

DRIFIRE® PRIME® FR SS / LS T-Shirt Chest Size

US Size	SMALL	MEDIUM	LARGE	X LARGE	2X LARGE	3X LARGE
Inches Centimetres	36 91.4	40 101.6	44 111.8	48 121.9	52 132.1	56 142.2

DRIFIRE® PRIME® FR Long-John Waist Size

US Size	SMALL	MEDIUM	LARGE	X LARGE	2X LARGE	3X LARGE
Inches Centimetres	28 71.1	31 78.7	34 86.4	37 94.0	40 101.6	43 111.8

How to Measure

DRIFIRE® base layers should be measured over your bare body or over very thin, tight-fitting undergarments like underwear. Because base layers are designed to sit directly against your skin to effectively wick away moisture and regulate your temperature, taking measurements over regular clothing will artificially inflate your size and result in a loose, baggy fit.

Care Instructions

- Read the garment label and launder per the instructions on the garment label.
- DO NOT use chlorine bleach or detergents containing bleach.
- DO NOT use fabric softeners.
- DO NOT iron.
- Wash/laundering instructions: Machine warm wash and tumble dry on low.
- Wash according to the instructions above to remove any contaminants in order to maintain fabric performance when the garment becomes soiled with dirt, grease or oils.
- If contaminants cannot be removed after laundering, it is best to discontinue use of the garment.

Continued



Men's Body Measurements Guide

1. Chest:

Measure around the fullest part.

2. Waist:

Measure around the natural waistline.

5. Sleeve Length:

Measure from the center back of the neck, across the shoulder and down to the wrist bone.

3. Seat (Hips):

Measure around the fullest part.

4. Inseam:

Measure from crotch seam to the ankle.

