



Size Chart

DRIFIRE® FR/AR Hi Vis Vented Work Shirt Class 3 (SHR__TGV) | 8.9 CAL | PPE CAT 2

US SIZE	SM	MD	LG	XL	2X	3X	4X	5X
CHEST Inches Centimetres	38 – 40 96.5 – 101.6	41 – 44 104.1 – 111.8	45 – 48 114.3 – 121.9	49 – 52 124.5 – 132.1	53 – 56 134.6 – 142.2	57 – 60 144.8 – 152.4	61 – 64 155.0 – 162.6	65 – 68 165.1 – 172.7
CENTRE BACK Inches Centimetres	32.50 82.55	33.0 83.82	33.50 85.09	34.00 86.36	34.50 87.63	35.00 88.90	35.50 90.17	36.00 91.44
SLEEVE LENGTH Inches Centimetres	34.50 87.63	35.00 88.90	36.00 91.44	36.75 93.345	37.50 95.25	37.50 95.25	37.50 95.25	37.50 95.25

Continued ▼

National Safety Apparel (NSA) measurements are true-to-size fit, meaning garments are engineered to correspond accurately to your actual body measurements, while built-in functional ease is added automatically to account for safety protocols and active movement on the job. Because NSA specialises in FR/AR PPE, their definition of a true-to-size fit prioritises safety compliance over fashion aesthetics.

You should take your actual body measurements using a fabric measuring tape. Measuring while wearing daily workwear will cause you to order a garment that is too large. Measure accurately and choose a garment size (SM, MD, LG, XL, 2X, 3X, 4X or 5X) based on your widest actual physical measurements. The size chart measurements are body measurements to help determine what size garment you should order. If your measurements fall between sizes, it is recommended that the larger size be purchased. Always round up to the larger size if your measurements fall between categories.

How to Measure (with assistance)

Chest

- Stand up straight with your arms relaxed at your sides.
- Have your assistant measure around the fullest part of your chest, under your arms and across your shoulder blades, ensuring the tape is level.

Centre Back

- Measure vertically from the base of the collar at the back of the neck straight down to the bottom edge hem of a well-fitting Shirt (preferably with an extended hem for enhanced coverage).

Sleeve Length (with assistance)

- Starting Point: Place the start of the tape measure at the nap of your neck (the prominent bone at the exact centre-back base of your neck).
- Path: Run the tape measure straight across the top of your shoulder.
- Arm Position: Bend your elbow slightly or place your fist on your hip. This creates the necessary "slack" for full range of motion.
- Ending Point: Continue tracking down the outside of your arm, past your elbow and stop at your wrist bone.

Having someone else take your body measurements is wise because it ensures greater accuracy, maintains proper posture and prevents tape skewing.

Tall 2" (5.08cms) longer and 1.5" (3.81cms) longer in the sleeve length than RG

Continued ▼

