



Size Chart

DRIFIRE® FR/AR TECGEN® Select® OFP Coverall | 8 CAL | PPE CAT 2

US SIZE	CHEST Inches Centimetres	SLEEVE LENGTH Inches / Cms	INSEAM Inches / Cms
SM	36 – 38 94.4 – 96.5	Regular	35.0 / 88.9
		Long	36.0 / 91.4
MD	40 – 42 101.6 – 106.7	Regular	35.5 / 90.2
		Long	36.5 / 92.7
LG	44 – 46 111.8 – 116.8	Regular	36.0 / 91.4
		Long	37.0 / 94.0
XL	48 – 50 121.9 – 127.0	Regular	36.5 / 92.7
		Long	37.5 / 95.3
2X	52 – 54 132.1 – 137.2	Regular	37.0 / 94.0
		Long	38.0 / 96.5
3X	56 – 58 142.2 – 147.3	Regular	37.5 / 95.3
		Long	38.5 / 97.8
4X	60 – 62 152.4 – 157.5	Regular	38.0 / 96.5
		Long	39.0 / 99.1
5X	64 – 66 162.6 – 167.7	Regular	38.5 / 97.8
		Long	39.5 / 100.3

Continued



DRIFIRE® FR/AR clothing is already designed oversized to fit over daily workwear. You should take your actual body measurements using a fabric measuring tape. Measuring while wearing daily workwear will cause you to order a garment that is too large.

Measure accurately and choose a garment size (SM, MD, LG, XL, 2X, 3X or 4X or 5X) based on your widest actual physical measurements. The size chart measurements are body measurements to help determine what size garment you should order. If your measurements fall between sizes, it is recommended that the larger size be purchased. Always round up to the larger size if your measurements fall between categories.

How to Measure (with assistance)

Chest

- Stand up straight with your arms relaxed at your sides.
- Have your assistant measure around the fullest part of your chest, under your arms and across your shoulder blades, ensuring the tape is level.

Sleeve Length (with assistance)

- Starting Point: Place the start of the tape measure at the nap of your neck (the prominent bone at the exact centre-back base of your neck).
- Path: Run the tape measure straight across the top of your shoulder.
- Arm Position: Bend your elbow slightly or place your fist on your hip. This creates the necessary "slack" for full range of motion.
- Ending Point: Continue tracking down the outside of your arm, past your elbow and stop at your wrist bone.

Inseam (with assistance)

- Measure vertically, from the top of your inner thigh to the ankle bone.
- Stand straight and have your assistant measure to avoid bending and distorting the measurement.
- Wear your work boots while checking the length.
- The hem must rest on the boot without dragging on the ground, which prevents tripping hazards and fabric tearing.
- You can also lay a pair of well-fitting Coveralls, Bib Overalls or Pants flat on a table and measure from the exact crotch intersection straight down the inner seam to the bottom cuff.

Having someone else take your body measurements is wise because it ensures greater accuracy, maintains proper posture and prevents tape skewing.

Continued



Guide for Measuring Actual Body Measurements

